


ASB-3C & 5C SPRING BALANCER

EXPLODED VIEW



PARTS LIST — FOR REFERENCE ONLY

Index Number	Description	Part Number		Qty.
		ASB-3C	ASB-5C	
1	CASE	203001-C	203001-C	1
2	DRUM BUSH	203002	203002	1
3	DRUM	203003-C	203003-C	1
4	SPIRAL SPRING	203004-C	205004-C	1
5	DRUM COVER	203005-C	203005-C	1
6	INTERNAL SCREW	SW415	SW415	3
7	SPINDLE	203006	203006	1
8	COVER	203007-C	203007-C	1
9	EXTERNAL SCREW (4*15)	SW415	SW415	5
10	MAIN HANGER	203008	203008	1
11	UPPER SWIVEL	203009	203009	1
12	CABLE SET	203010	203010	1
12 - 1	LOCK	-	-	1
12 - 2	CABLE	-	-	1
12 - 3	SHOCK ABSORBER	-	-	1
12 - 4	NUT	-	-	1
12 - 5	BOLT	-	-	1
12 - 6	CABLE STOP	-	-	1

Index Number	Description	Part Number		Qty.
		ASB-3C	ASB-5C	
12 - 7	LOCK	-	-	1
12 - 8	THIMBLE	-	-	1
12 - 9	TOOL CLIP	-	-	1
13	SPINDLE CAP	203011	203011	1
14	RATCHET CAP	203012-C	203012-C	1
15	RATCHET	203014	203014	1
16	SCREW(M6*10)	203015	203015	1
17	CASE INSERT	203016	203016	1
18	RATCHET GEAR	203017	203017	1
19	KEY	203018	203018	1
20	RATCHET SPRING	203019	203019	1
21	CABLE BOLT	203020	203020	1

NOTES

See ASB-3C and ASB-5C Spring Balancer manual for complete operating and safety instructions before use.