



DS/LI36x8

HOW TO SPEC GUIDE

Version: 1.5
North America



CORDED



	Description	SKU
LI3608-SR 1D Linear - Standard Range	Standard Range 1D Barcodes Only Can Read off of LCD Displays	LI3608-SR00003VZWW
LI3608-ER 1D Linear - Extended Range	Extended Range 1D Barcodes Only Can Read off of LCD Displays	LI3608-ER20003VZWW
DS3608-SR 2D Standard Range	Standard Range 1D/2D Barcodes, Basic Image Capture Can Read off of LCD Displays	DS3608-SR00003VZWW
DS3608-HP 2D High Performance	Mid-Range 1D/2D Barcodes, Advanced Image Capture Can Read off of LCD Displays	DS3608-HP20003VZWW
DS3608-HD 2D High Density	Small Dense (Tiny) Barcodes 1D/2D Barcodes, Basic Image Capture Can Read off of LCD Displays	DS3608-HD20003VZWW
DS3608-ER 2D Extended Range	Extended (All) Range 1D/2D Barcodes, Basic Image Capture Can Read off of LCD Displays	DS3608-ER20003VZWW
DS3608-DP 2D Direct Part Mark	Direct Part Mark (DPM) Barcodes Basic Image Capture	DS3608-DP20003VZWW



CORDLESS

	Description	SKU
LI3678-SR 1D Linear – Standard Range	Standard Range 1D Barcodes Only Can Read off of LCD Displays	LI3678-SR0F003VZWW
LI3678-ER 1D Linear - Extended Range	Extended Range 1D Barcodes Only Can Read off of LCD Displays	LI3678-ER2F003VZWW
DS3678-SR 2D Standard Range	Standard Range 1D/2D Barcodes, Basic Image Capture Can Read off of LCD Displays	DS3678-SR0F003VZWW
DS3678-HP 2D High Performance	Mid-Range 1D/2D Barcodes, Advanced Image Capture Can Read off of LCD Displays	DS3678-HP2F003VZWW
DS3678-HD 2D High Density	Small Dense (Tiny) Barcodes 1D/2D Barcodes, Basic Image Capture Can Read off of LCD Displays	DS3678-HD2F003VZWW
DS3678-ER 2D Extended Range	Extended (All) Range 1D/2D Barcodes, Basic Image Capture Can Read off of LCD Displays	DS3678-ER2F003VZWW
DS3678-DP 2D Direct Part Mark	Direct Part Mark (DPM) Barcodes Basic Image Capture	DS3678-DP2F003VZWW

*All cordless models FIPS rated



CRADLES



	Description	SKU
Standard Cradle	Charger and Bluetooth	STB3678-C100F3WW
Forklift Cradle	IP65 Sealed, Charger, and Bluetooth	FLB3678-C100F3WW



Forklift Vibration Dampening Mounting Plate [Order Separately]	BRKT-MM0036W-00
---	-----------------

CORDED BUNDLES



<div>LI3608-SR3U4600VZW</div> <div><div>Scanner – LI3608-SR</div><div>USB Cable – CBA-U46-S07ZAR</div></div>	<div>LI3608-ER3U4600ZVW</div> <div><div>Scanner – LI3608-ER</div><div>USB Cable – CBA-U46-S07ZAR</div></div>	<div>DS3608-SR3U4600VZW</div> <div><div>Scanner – DS3608-SR</div><div>USB Cable – CBA-U46-S07ZAR</div></div>
<div>DS3608-HP3U4602VZW</div> <div><div>Scanner – DS3608-HP</div><div>USB Cable – CBA-U46-S07ZAR</div></div>	<div>DS3608-ER3U4602ZVW</div> <div><div>Scanner – DS3608-ER</div><div>USB Cable – CBA-U46-S07ZAR</div></div>	<div>DS3608-HD3U4602VZW</div> <div><div>Scanner – DS3608-HD</div><div>USB Cable – CBA-U46-S07ZAR</div></div>
	<div>DS3608-ER3U42A2ZVW</div> <div><div>Scanner – DS3608-ER</div><div>USB Cable – CBA-U42-S07PAR</div><div>Power Supply – PWR-BGA12V50W0WW</div><div>DC Line Cord – CBL-DC-451A1-01</div><div>[AC Line Cord – 23844-00-00R] Not Included</div></div>	<div>DS3608-DP3U4602ZVW</div> <div><div>Scanner – DS3608-DP</div><div>USB Cable – CBA-U46-S07ZAR</div></div>
	<div>DS3608-ER3UF202ZVW</div> <div><div>Scanner – DS3608-ER</div><div>VC70 Series A Lock Cable – CBA-UF2-C12ZAR</div></div>	



CORDLESS BUNDLES

LI3678-SR3U4210S1W

Scanner – LI3678-SR
Standard Cradle – STB3678-C100F3WW
USB Cable – CBA-U42-S07PAR
Power Supply – PWR-BGA12V50W0WW
DC Line Cord – CBL-DC-451A1-01
AC Line Cord – 23844-00-00R

LI3678-ER3U4210S1W

Scanner – LI3678-ER
Standard Cradle – STB3678-C100F3WW
USB Cable – CBA-U42-S07PAR
Power Supply – PWR-BGA12V50W0WW
DC Line Cord – CBL-DC-451A1-01
AC Line Cord – 23844-00-00R

DS3678-SR3U4210SFW

Scanner – DS3678-SR
Standard Cradle – STB3678-C100F3WW
USB Cable – CBA-U42-S07PAR
Power Supply – PWR-BGA12V50W0WW
DC Line Cord – CBL-DC-451A1-01
AC Line Cord – 23844-00-00R

DS3678-HP3U4210SFW

Scanner – DS3678-HP
Standard Cradle – STB3678-C100F3WW
USB Cable – CBA-U42-S07PAR
Power Supply – PWR-BGA12V50W0WW
DC Line Cord – CBL-DC-451A1-01
AC Line Cord – 23844-00-00R

DS3678-ER3U4212SVW

Scanner – DS3678-ER
Standard Cradle – STB3678-C100F3WW
USB Cable – CBA-U42-S07PAR
Power Supply – PWR-BGA12V50W0WW
DC Line Cord – CBL-DC-451A1-01
AC Line Cord – 23844-00-00R

DS3678-HD3U4210SFW

Scanner – DS3678-HD
Standard Cradle – STB3678-C100F3WW
USB Cable – CBA-U42-S07PAR
Power Supply – PWR-BGA12V50W0WW
DC Line Cord – CBL-DC-451A1-01
AC Line Cord – 23844-00-00R

DS3678-ER3U4602FVW

Scanner – DS3678-ER
Forklift Cradle – FLB3678-C100F3WW
USB Cable – CBA-U46-S07ZAR
Mounting Bracket – BRKT-MM0036W-00

DS3678-DP3U4212S1W

Scanner – DS3678-DP
Standard Cradle – STB3678-C100F3WW
USB Cable – CBA-U42-S07PAR
Power Supply – PWR-BGA12V50W0WW
DC Line Cord – CBL-DC-451A1-01
AC Line Cord – 23844-00-00R



USB-A

CBA-U46-S07ZAR

Cable - Shielded USB: Series A Connector, 7ft. (2m), Straight

CBA-U47-S15ZAR

Cable - Shielded USB: Series A Connector, 15ft. (4.6m), Straight

OR

CBA-UF8-C12ZAR

Cable - Shielded USB: Series A Connector, 12ft. (3.6m), Coiled,
BC 1.2 [-30C]





USB-A

With External Power Supply

CBA-U42-S07PAR

Cable - Shielded USB: Series A Connector, 7ft. (2m), Straight
[Requires External 12v Power Supply]

CBA-U44-S15PAR

Cable - Shielded USB: Series A Connector, 15ft. (4.6m), Straight
[Requires External 12v Power Supply]



+



+



+



PWR-BGA12V50W0WW
Power Supply
12v, 4.16A

CBL-DC-451A1-01
DC Line Cord

23844-00-00R
AC Line Cord




USB-POWER PLUS

CBA-U43-S07ZAR

Cable - Shielded USB: Power Plus Connector, 7ft. (2m), Straight

CBA-U45-S15ZAR

Cable - Shielded USB: Power Plus Connector, 15ft. (4.6m), Straight





RS232

CBA-R71-C09ZAR

Cable – RS232: DB9 Female Connector, 9ft (2.8m) Coiled,
Powered Pin 9

CBA-RF2-C09ZAR

Cable – RS232: DB9 Female Connector, 9ft (2.8m) Coiled,
Powered Pin 9 [-30C]



[Note: 5v Power must come on Pin 9 from Host – If it does not please see next slide for External Power Supply setup]



RS232

With External Power Supply

CBA-R07-S07PAR

Cable – RS232: DB9 Female Connector, 7ft. (2m), Straight
[Requires External 12v Power Supply]

CBA-R21-S15PAR

Cable – RS232: DB9 Female Connector, 15ft. (4.6m), Straight
[Requires External 12v Power Supply]



+



+




+



PWR-BGA12V50W0WW
Power Supply
12v, 4.16A

CBL-DC-451A1-01
DC Line Cord

23844-00-00R
AC Line Cord



FORKLIFT MOUNT (VMU) SETUP



VH10

CBA-R71-C09ZAR

Cable – RS232: DB9 Female Connector, 9ft (2.8m) Coiled,
Powered Pin 9

OR

CBA-U46-S07ZAR

Cable - Shielded USB: Series A Connector, 7ft. (2m), Straight

OR

CBA-U47-S15ZAR

Cable - Shielded USB: Series A Connector, 15ft. (4.6m), Straight





VH10F



CBA-RF2-C09ZAR

Cable – RS232: DB9 Female Connector, 9ft (2.8m) Coiled,
Powered Pin 9 [-30C]

OR

CBA-UF1-S07ZAR

Cable - Shielded USB: Series A Connector, 7ft. (2m), Straight [-30C]

OR

CBA-UF8-C12ZAR

Cable - Shielded USB: Series A Connector, 12ft. (3.6m), Coiled,
BC 1.2 [-30C]





VC70

CBA-UF7-C12ZAR

Cable – USB Series A Locking Connector for VC70, 12' Coiled

OR

CBA-R71-C09ZAR

Cable – RS232: DB9 Female Connector, 9ft (2.8m) Coiled,
Powered Pin 9

OR


CBA-U46-S07ZAR

Cable - Shielded USB: Series A Connector, 7ft. (2m), Straight

OR

CBA-U47-S15ZAR

Cable - Shielded USB: Series A Connector, 15ft. (4.6m), Straight





VC70F



CBA-UF7-C12ZAR

Cable – USB Series A Locking Connector for VC70, 12' Coiled

[-30C]

OR

CBA-RF2-C09ZAR

Cable – RS232: DB9 Female Connector, 9ft (2.8m) Coiled,
Power Pin 9 **[-30C]**

OR

CBA-UF1-S07ZAR

Cable - Shielded USB: Series A Connector, 7ft. (2m), Straight **[-30C]**

OR

CBA-UF8-C12ZAR

Cable - Shielded USB: Series A Connector, 12ft. (3.6m), Coiled,
BC 1.2 **[-30C]**





VC80

CBA-R71-C09ZAR

Cable – RS232: DB9 Female Connector, 9ft (2.8m) Coiled,
Powered Pin 9

OR

CBA-U46-S07ZAR

Cable - Shielded USB: Series A Connector, 7ft. (2m), Straight

OR

CBA-U47-S15ZAR

Cable - Shielded USB: Series A Connector, 15ft. (4.6m), Straight





VC80F



CBA-RF2-C09ZAR

Cable – RS232: DB9 Female Connector, 9ft (2.8m) Coiled,
Power Pin 9 [-30C]

OR

CBA-UF1-S07ZAR

Cable - Shielded USB: Series A Connector, 7ft. (2m), Straight [-30C]

OR

CBA-UF8-C12ZAR

Cable - Shielded USB: Series A Connector, 12ft. (3.6m), Coiled,
BC 1.2 [-30C]





VC5090

CBA-UF3-C09ZAR

Cable – Shielded USB: Amphenol Threaded Circular Connector for VC5090, 9ft (2.8m) Coiled

OR

CBA-RF4-C09ZAR

Cable – RS232: Amphenol Threaded Circular Connector for VC5090, 9ft (2.8M) Coiled

OR

CBA-UF5-C09ZAR

Cable – USB, RS232 “Y” Power Stealer, 9ft Coiled, DS3600 to VC5090, [-30C]

Required for DS3608-ER only to run at full power





CORDLESS CHARGING ACCESSORIES

FOR DS/LI3678 DEVICES



SAC3600-4001CR
4-Slot Battery Charger



PWR-BGA12V50W0WW
Power Supply
12v, 4.16A

+



CBL-DC-375A1-01
DC Line Cord

+



23844-00-00R
AC Line Cord

SAC3600-KIT

Kit Part# includes all of the above



BTRY-36IAB0E-00
Spare Battery for DS/LI3678



FIX MOUNT ACCESSORIES



STND-AS0036-07
Adjustable Intellistand



21-52612-01R
Forklift Holder



1000225
Scanner Holder



50-15400-031
Tool Balancer Pulley



50-12500-066
Wrist Strap



VEHICLE POWER SETUP

[NOTE: The DS/LI3678 and FLB3678 can draw charge from the Vehicle Mount Computer – In that case this setup is not necessary]



PQRS-14000-251R

DC/DC High Voltage Power Converter, Input: **18-75V**, 2.4A, Output: 12V, 2.5A. For nominal voltage input of **36V, 48V, and 60V systems**. It cannot be used with the VC6096.

OR



PQRS-14000-252R

DC/DC Low Voltage Power Converter, Input: **9-30V**, 4.4A, Output: 12V, 2.5A. For nominal voltage input of **12V and 24V systems**.

+



CBL-36-452A-01

Forklift DC Power Supply Adapter Cable For Use With -251 and -252 DC To DC Power Supplies

+



CBA-xxx-xxxPAR

NOTE: A Powered Communication Cable is required between CBL-36-452A-01 and FLB3678: Please refer to Slide 8 or 11 for compatible cable options.

