

# Application Instructions Reztore™ ESD Hand Lotion and Reztore™ Clean Hand Lotion



Made in the  
United States of America



Figure 1. Reztore™ ESD Hand Lotion.

## Description

Desco Industries, Inc. Reztore™ ESD Hand Lotion and Reztore™ Clean Hand Lotion are specially formulated for use in the electronic manufacturing environment. Per ESD Handbook TR20.20 paragraph 5.3.2.4.3 Test Procedure, "If the [wrist strap test] resistance is still too high, dry skin might be the problem. Dry skin conditions can be resolved by applying moisturizing lotion on the wrist and repeating the resistance test again. The moisturizing lotion should be one that is compatible with process requirements." The moisturizing hand lotion can be used to enhance the effectiveness of ESD control wrist straps, particularly for individuals with dry skin. It will absorb immediately into the skin without interfering with grip or dexterity. The lotion is free of chemicals that may adversely affect solderability or cause corrosion of electronic components. Reztore™ Hand Lotion is available in 8 oz. (235 ml) plastic bottles (sold in cartons of twelve bottles), 32 oz. (1 litre) bottles with pumps, or in one 1 gallon (3.8 litre) bottles with pumps.

Reztore™ Hand Lotion can also be used with ESD footwear. Per ESD Handbook TR20.20 section 5.3.3.5 Common Testing Problems "Occasionally, footwear may indicate a high resistance. Outside of the shoe material itself being a contributor to high resistance, the wearer's skin (if dry), heavy or insulative socks, or the absence of a sweat layer due to differences in temperature between the inner surfaces of the shoes and the wearer's feet."

## General Guidelines

Reztore™ Hand Lotion can be applied to hands and wrists to increase the conductivity of the skin and reduce skin dryness. It is not recommended for application to the face. The lotion is chemically and biologically stable and is free of soaps, glycerin, lanolin, silicone and mineral oil. Avoid contact with eyes. If eye contact occurs wash with water.

## Directions

Apply a small amount of Reztore™ Hand Lotion onto the palm of the hand. Using your hands, rub the lotion into skin areas which are either dry or where increased conductivity is desired, especially on the wrists where the wrist strap will be in direct contact. Gently rub the lotion into the skin until it is absorbed. Remove the excess lotion with a towel.

## Specifications

<b>Color:</b>	White
<b>Odor:</b>	Pleasant
<b>pH:</b>	7.5 ± .5
<b>Contaminants:</b>	No soap, lanolin, silicones, or mineral oil
<b>% Solids:</b>	7.5 ± 2%
<b>Package:</b>	8 oz. (235 ml) plastic squeeze bottles, 32 oz. (1 litre) bottles with pumps, or 1 gallon (3.8 litre) bottles with pumps
<b>Freeze:</b>	Passes three freeze-thaw cycles

## Features - Benefits

- Moisturizing formula improves wrist strap contact with skin and relieves chapping and insulating dry skin
- Free of contaminants so that nothing is transferred to the work
- Non-acidic to prevent corrosion of electronic components
- Contains aloe vera, moisturizers, and vitamins to promote healing and help achieve healthier hands and nails
- No lanolin, silicone, mineral oil, or insulators that will contaminate electronic components

**NOTE:** Reztore™ Hand Lotion does not have a set life span. The chemicals are not known to degrade over time when stored at the proper temperature conditions as stated in the Material Safety Data Sheet. We also recommend that this product be stored in its original container and be sealed when not in use.

**Limited Warranty**

Desco Industries, Inc. expressly warrants that for a period of one (1) year from the date of purchase, our Reztore™ ESD Hand Lotion and Reztore™ Clean Hand Lotion will be free of defects in material. Within the warranty period, the material will be replaced at our option, free of charge. Call our Customer Service Department at 781-821-8370 or 00 44 (0) 1892-665313 in Europe for a Return Material Authorization (RMA) and proper shipping instructions and address. You should include a copy of your original packing slip, invoice, or other proof of purchase date. Any material under warranty should be shipped prepaid to the Desco Industries, Inc. factory. Warranty replacements will take approximately two weeks.

**Warranty Exclusions**

THE FOREGOING EXPRESS WARRANTY IS MADE IN LIEU OF ALL OTHER PRODUCT WARRANTIES, EXPRESSED AND IMPLIED, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE WHICH ARE SPECIFICALLY DISCLAIMED. The express warranty will not apply to defects or damage due to accidents, neglect, misuse, alterations, operator error, or failure to properly maintain, clean, or repair products.

**Limit of Liability**

In no event will Desco Industries, Inc. or any seller be responsible or liable for any injury, loss, or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, users shall determine the suitability of the product for their intended use, and users assume all risk and liability whatsoever in connection therewith.