

# **Sterile 70% Isopropanol**

**Trigger Spray** 

### TECHNICAL DATA SHEET



### Sterile 70% Isopropanol

- \* Gamma-irradiated to a sterility level of  $10^{\circ}$  with independent QC audits to ensure sterility
- · Each lot tested for endotoxins
- · Lot traceable
- Lot-specific information on each shipment simplifies record keeping:
  - » Certificate of Processing confirming radiation dosage
  - Certificates of Compliance and Analysis
  - Expiration date marked on each package

## **Description**

Texwipe's Sterile 70% Isopropanol contains 70% by volume USP-grade Isopropanol (isopropyl alcohol) and 30% USP-purified water. This solution is submicron filtered, filled into cleaned containers, double-bagged and gamma-irradiated. Each bottle is lot coded with an expiration date for easy recordkeeping.

Bottles are fully-assembled and ready for use — no unpacking, handling or attaching spray heads is required. The adjustable spray head offers stream delivery or coarse spray.

# **Applications**

- ➤ Surface cleaning
- ▶ Use on gloved hands in sterile suites
- ► Wipe down for pass through to controlled environments
- ► Ideally suited for use with sterile cleanroom wipers

#### **Features**

- ► 0.2 µm filtered 70% USP-grade Isopropanol (Isopropyl Alcohol)
- ▶ Non-atomizing adjustable spray
- ▶ 5 color indicator dots (for identification)
- ► Double-bagged in solvent-safe packaging
- ► Meets FDA guideline for medical device bacterial endotoxin limit of not more than 20 EU/device

#### **Benefits**

- Ready-to-use sprayer eliminates handling and assembly, maintaining sterility
- Removes many surface contaminants
- ► Evaporates and leaves extremely low residue
- ► Prefiltered and sterilized for pass through and use in critical environments
- ► Eliminates mixing, filtration, processing and QC expense of in-house production of sterile IPA

#### **Products**

Number	Description	Size	Packaging
Mini-Cases			
TX3274	Sterile 70% Isopropanol trigger spray	16 fluid ounces (473 mL)	4 polybottles/case
Full-Cases			
TX3270	Sterile 70% Isopropanol trigger spray	16 fluid ounces (473 mL)	12 polybottles/case
TX3273	Sterile 70% Isopropanol trigger spray	32 fluid ounces (946 mL)	12 polybottles/case
TX8270	Sterile 70% Isopropanol trigger spray	8 fluid ounces (237 mL)	12 polybottles/case

**North America:** 1210 South Park Drive, Kernersville, NC 27284 • Tel 336.996.7046 • Fax 336.996.2297

Europe/Middle East: Saffierlaan 5, 2132 VZ Hoofddorp, The Netherlands • Tel +31 88 1307 400 • Fax +31 88 1307 499

Asia/Pacific: ITW Singapore (Pte) Ltd., 500 Chai Chee Lane, Singapore 469024 • Tel +65 6468 9433 • Fax +65 6468 6772

www.texwipe.com Distributed by: www.all-spec.com, 800-537-0351 ©2013 ITW Texwipe Printed in USA • Effective: April 2013



# **Sterile 70% Isopropanol**

# Convenient Trigger Spray

TECHNICAL DATA SHEET

TX3270, TX3273, TX3274, TX8270

Product Characteristics		
Property	Description	
IPA Quality	Meets the requirements of USP Isopropyl Alcohol	
Water Quality	Meets the requirements of USP Purified Water	
Appearance	Clear, colorless liquid	
Odor	Characteristic alcohol	
% IPA Content	68% – 72%	
Specific Gravity	0.872 - 0.883	
Acidity	Not more than 1.0 mL of 0.020 N Sodium Hydroxide	
Limit of NVR	Does not exceed 5 mg (0.01%)	

# Certificate of Analysis provided with every lot.

Distributed by:

All-Spec, a Hisco Subsidiary

Ph: 800-537-0351

Web: <a href="www.all-spec.com">www.all-spec.com</a>

Wilmington, NC

Fx: 800-379-9903

Email: <a href="mailto:sales@all-spec.com">sales@all-spec.com</a>