



Light Duty



Multi-Purpose

Sacrifice your glove, nothing else!

- **Significantly minimizes the risk of severe injury if the glove becomes entangled in a rotating tool**

The only ultrathin assembly glove designed to easily tear apart at multiple high risks areas.

- **Provides the tactility needed to grab even the smallest parts**

Ultrathin liner delivers extreme tactility when a high degree of precision is required.

- **Delivers the comfort your hands deserve!**

ZONZ™ Comfort Fit Technology offers extreme breathability to keep hands cool and comfortable.



Industries

- Automotive & Transportation
- Machinery & Equipment
- Maintenance
- Metal Fabrication

Applications

- Final assembly
- Light assembly application requiring a high degree of precision

Key Features

- **Easily tears at multiple risk areas.**
Unique and patented knitted design allows the glove to easily tear at multiple high risk areas, significantly reducing the risk of hand injury if the glove becomes entangled in a rotating tool.
- **Ultra thin design.**
Provides excellent tactility to grab even the smallest parts.
- **ZONZ technology for enhanced comfort.**
Offers extreme breathability to keep hands cool and comfortable.
- **Product protection.**
White color allows for quick identification of dirt to avoid product contamination.
- **Silicone free.**
No transfer of silicone contaminants to metal parts prior to painting.

Performance Standards



Technologies



Specifications

| BRAND STYLE | DESCRIPTION | SIZE | LENGTH | COLOR | PACKAGE |
|----------------|--|------|-------------|------------------------------|------------------------------|
| HyFlex® 11-812 | Type: Palm dipped coated Coating Material: Foam Nitrile Liner Material: Nylon, spandex Cuff Style: Knit wrist | 6-10 | 8-10 inches | white coating on white liner | 12 pairs/bag, 12 bags/carton |

Usage Precautions

- This glove will not directly protect the worker from injuries caused by contact with a sharp or high-speed rotating machine.
- If a glove becomes entangled in a rotating machine, whether or not it tears, it should be discarded and not used again.
- An in-depth analysis of the application requirements through Ansell Guardian is essential before use.

For additional information visit us at www.ansell.com or contact us at:

Ansell Healthcare Products LLC

111 Wood Avenue South
Suite 210
Iselin, NJ 08830, USA
+1 800 800 0444
Fax: +1 800 800 0445

Ansell Canada, Inc.

105 Lauder
Cowansville, QC,
J2K 2K8 Canada
+1 800 363 8340
Fax: +1 888 267 3551