

# Flexane® Fast Cure Rubber Repair Putty

**Description:** A fast-curing, flexible urethane for repairing rubber equipment.

**Intended Use:** Repair worn or damaged rubber equipment; form protective linings in equipment subject to wear, impact, abrasion, vibration, expansion, and contraction.

**Product features:**

**Limitations:** None

**Typical Physical Properties:** *Technical data should be considered representative or typical only and should not be used for specification purposes.*

**Cured 7 days @ 75° F**

<b>Color</b>	<b>Black</b>
<b>Mix Ratio</b>	<b>80:20</b>
<b>Mixed Viscosity</b>	<b>Thixotropic paste</b>
<b>% Solids by Volume</b>	<b>100</b>
<b>Specific Volume</b>	<b>23.5 in.(3) /lb.</b>
<b>Cured Shrinkage</b>	<b>0.0014 in./in.</b>
<b>Maximum Operating Temperature</b>	<b>Dry: 180°F; Wet: 120°F</b>
<b>Coverage / lb</b>	<b>94 sq.in./lb. @ 1/4"</b>
<b>Cured Hardness</b>	<b>87A</b>
<b>Dielectric Strength</b>	<b>350 volts/mils</b>
<b>Tensile Strength</b>	<b>2,400 psi</b>
<b>Tear Resistance</b>	<b>275 pli</b>
<b>Maximum Elongation</b>	<b>500%</b>
<b>Abrasion Resistance</b>	<b>220mg loss per 1,000 rev. (CS17 wheel/1K cycles)</b>
<b>Functional Cure Time</b>	<b>16 hrs.</b>
<b>Light Duty Service</b>	<b>2 hrs.</b>
<b>Pot Life</b>	<b>8 min. @ 75°F</b>

**TESTS CONDUCTED**

- Cure Shrinkage ASTM D 2566
- Tear Resistance ASTM D 624
- Maximum Elongation ASTM D 412
- Dielectric Strength, volts/mil ASTM D 149
- Cured Hardness Shore D ASTM D 2240
- Tensile Strength (Urethanes) ASTM D 412

**Surface Preparation:** For METAL SURFACES, thoroughly clean area to be repaired, rebuilt, or lined with Devcon® Cleaner Blend 300. Remove any oil, grease, or dirt. Roughen surface by grinding with a coarse wheel or an abrasive disc pad. To prime this surface, apply a coat of Devcon FL-10 Primer and allow to dry tack-free for 15 minutes. If the metal surface requires maximum tear resistance or is exposed to moisture, or if submerged in water, use Devcon® FL-10 and Devcon® FL-20 Primer.

For RUBBER SURFACES, thoroughly clean area with an abrasive pad and Devcon® Cleaner Blend 300. Surface can also be roughened with a grinding wheel so that it is coarse and free from oil and dirt that may clog the "pores" of the rubber. Wipe or roughen surface with Cleaner Blend 300 until the cloth no longer picks up the color of the rubber. The rubber should appear new or deeper in color. To prime this surface, apply a coat of Devcon® FL-20 Primer and allow to dry tack-free for 15-20 minutes. Use Devcon® FL-40 Primer on "hard-to-bond" rubber surfaces as this gives ultimate peel resistance. Multiple coats may be necessary for porous rubber surfaces.

For MAXIMUM ADHESION, sandblast the surface with an angular abrasive until a minimum depth profile of 2-3 mils is met. Blast to near-white finish specification SSPC-SP5 (Steel Structure Painting Council). Prime surface immediately after sandblasting to prevent oxidation.

**Mixing Instructions:** ---- To ensure proper cure speeds and hardness, mix Flexane at a temperature between 65°F-85°F. ----

1. Add hardener to resin.
2. Vigorously mix with screwdriver or spatula for two minutes, while continuously scraping material away from sides and bottom of container. NOTE: Flexane putties will thicken rapidly during these first two minutes of mixing, but this DOES NOT mean that the polymer is curing.
3. Transfer the mixed material to the plastic container (included in kit).
4. Wipe spatula clean, and stir again for two more minutes.
5. Continue to mix until a uniform, streak-free consistency is obtained.

FOR 4LB. UNITS:  
Use a propeller-type Jiffy Mixer Model ES on an electric drill.

Mix until color is uniform and consistent (approx 4-6 min.), while continuously scraping material away from sides and bottom of container.

NOTE: Completely submerge propeller, otherwise large amounts of air will be added resulting in air bubbles on the finished product's surface.

**Application Instructions:**

1. Mount cartridge onto manual gun (#15043) or pneumatic gun (#15041).
2. Attach #15047 mix nozzle (used with both cartridges).
3. Clip mix nozzle back to desired orifice size.
4. Squeeze cartridge, allowing first THREE INCHES of material to discharge until a unified mix is exuding from nozzle, (color is uniform with no striations).
5. Finish application as quickly as possible.

**IMPORTANT:**

Replace mix nozzle every four minutes to ensure complex mix, with no soft spots. Because of the short pot life (8 minutes), stopping between uses can result in Flexane product curing IN the mix nozzle. Further mixing will be off ratio.

**Storage:**

Store at room temperature.

**Compliances:**

None

**Chemical Resistance:**

*Chemical resistance is calculated with a 7 day, room temp. cure (30 days immersion) @ 75°F*

1,1,1-Trichloroethane	Poor	Phosphoric 10%	Very good
Aluminum Sulfate 10%	Very good	Potassium Hydroxide 40%	Very good
Cutting Oil	Fair	Sodium Hydroxide 50%	Very good
Gasoline (Unleaded)	Poor	Sodium Hypochlorite	Very good
Hydrochloric 10%	Very good	Xylene	Poor
Hydrochloric 36%	Very good		
Isopropanol	Poor		
Methyl Ethyl Ketone	Poor		

**Precautions:**

Please refer to the appropriate material safety data sheet (MSDS) prior to using this product.

**For technical assistance, please call 1-800-933-8266**

**FOR INDUSTRIAL USE ONLY**

**Warranty:**

Devcon will replace any material found to be defective. Because the storage, handling and application of this material is beyond our control, we can accept no liability for the results obtained.

**Disclaimer:**

All information on this data sheet is based on laboratory testing and is not intended for design purposes. ITW Devcon makes no representations or warranties of any kind concerning this data.

**Order Information:**

**15049 400 ml cartridge**

**Distributed by:**

All-Spec Industries 800-537-0351 (phone)  
Wilmington, NC 800-379-9903 (fax)  
www.all-spec.com sales@all-spec.com